



P.O. Box 14421 • Columbus, Ohio 43214 • (614) 284-8521  
[www.pickguardian.com](http://www.pickguardian.com)

---

### **ES-335 Type Bracket/Guard Installation**

What you'll need:

Phillips head screw driver

Clear 5-Minute Epoxy Cement

Paper or Masking Tape

- 1) Protect top of guitar with paper or masking tape.
- 2) Line up bracket on ledge of the guitar with clear block sitting on top of guitar.
- 3) Screw bracket to side of guitar.
- 4) Mix epoxy and apply a small amount to top of clear block.
- 5) Line up guard on guitar making sure not to let it touch the clear block.
- 6) Press guard onto clear block and hold.
- 7) Loosely screw the guard down near the neck.
- 8) Let guitar lay flat until glue sets up completely (3-4 hours).
- 9) Tighten screw near the neck.